


Getting Started

DISPLAY PANEL



- | | |
|--|-----------------------------|
| 1) Weather Alert Modes | 8) Timer Active Indicator |
| 2) Memory Location (1 - 5) | 9) Clock Seconds |
| 3) Key Lock On/Off | 10) Frequency/Clock Display |
| 4) Sleep Timer/Snooze Status | 11) Alarm Status and Type |
| 5) Battery Symbol | 12) AM/PM Indicator |
| 6) Battery Power Level Indicator and Signal Strength Meter | 13) Indicates Band In Use |
| 7) Squelch Indicator | 14) AUX IN Indicator |
| | 15) Stereo Reception |